

1

16CH Network Video Server Quick Installation Guide

nVS-16 Slim

- Product Front View



Product Rear View



Notes:

- * nVS-16 slim doesn't support POE function. Thus, please input the DC12V, 1.2A (min) electric power in the DC12V In (pin-3) and Gnd (pin-4).
- * Please use the **CAT-6** RJ-45 cable to connect each Telexper devices.
- * Please use the **75Ω** coaxial video cable connecting the camera to the video server.
- * The DC12V Output at **pin-5** provides the **max 8W** electric power.
- * The effective distance away from the PoE Hub is 100 meters.

IP CCTV Solution Configuration

